Grafica™
Graphic LCD Keypad
User's Quick Reference Guide

AC LIGHT
ON = AC power
OFF = Power failure

Fire   Auxiliary   Emergency
Panic Keys (press and hold)

Use the **Action Keys** to select an option shown above the Action Key on the screen.

Action Keys

Scroll Keys

Navigate the User Menu with the **Scroll Keys**.

How To Use Grafica

Method 1: Using Your Code

1) From the System Status screen, enter your **code #** (PIN).
2) Use the Scroll Keys to navigate the User Menu* and highlight an option.
3) Press the center action key (**OK**).
4) Follow the on-screen instructions.

Method 2: Using One-Touch Options

1) From the System Status screen, press the right action key (**Menu**).
2) Use the Scroll Keys to navigate the User Menu* and highlight an option.
3) Press the center action key (**OK)** to enable the option.

One-Touch Options must be enabled on all displayed partitions otherwise you will be prompted to enter your **code #** (PIN).

*The User Menu options may vary according to your user profile.

Arm System: Arms entire area when all zones are closed.

Disarm: Disarms entire area.

Stay Arm: Arms area's perimeter only, which allows you to remain in the protected area.

Force Arm: Arms entire area without waiting for all zones to close.

Instant Arm: Same as *Stay* arming, except that an alarm occurs instantly if any armed zones are opened, including entry delay zones.

Alarm Memory: Displays a record of recently triggered alarms.

Trouble: Displays a list of system troubles.

Bypass: Deactivates specific zones the next time the system is armed.

View Status: View floor plans and the status of zones, events and areas.

Programming: Program user codes, user profiles, timed auto-arming and send test reports.

Alarm Clock: Set the alarm clock.

Keypad Settings: Set the system tones, LCD contrast, backlight and more.

Some features in this Quick Start need to be activated by your installer.
We recommend that you test your system on a weekly basis. Please refer to the appropriate user manual.